

Bohrschablone

Bitte beachten Sie, dass der Haken nicht vertikal montiert werden sollte, sondern wie unten erläutert. So zeigen beide Zweige nach oben und können als Aufhängung genutzt werden. Um die richtige Position zu bestimmen, benutzen Sie bitte diese (Papier)-Bohrschablone.

SCHRITT 1

Positionieren Sie die Bohrschablone dort, wo Sie den Haken montieren möchten.

SCHRITT 2

Mit Hilfe einer Wasserwaage wird die waagerechte Linie (s.u.) ausgerichtet.

SCHRITT 3

Stechen Sie mit einem Bleistift in die beiden Kreise. Bohren Sie nun in die zwei entstandenen Markierungen auf der Wand Ihre Bohrlöcher (\varnothing 3,6 mm).

Drilling template

Please note that the hook should not be mounted vertically, but as explained below. This way, both branches point upwards and can be used as a suspension. To determine the correct position, please use this (paper) drilling template.

STEP 1

Place the template where you wish to mount the hook.

STEP 2

With the help of a spirit level align the template with the horizontal line drawn on the template.

STEP 3

Poke the tip of a pencil through each hole and make a mark on the wall. These are your drilling guide marks (\varnothing 3,6 mm).

